F 5.5

WB FILLER **PRODUCT INFORMATION**



JUNCKERS

GENERAL DESCRIPTION

- Fast drying, water-based gap filler designed to fill joints and gaps in wooden floors.
- VOC-content = 0.
- Particularly suitable for industrial parquet and patterned floors such as herringbone flooring.
- Mixed with sanding dust, the filler can be used to fill gaps up to 2 mm wide.
- Not suitable for plank floors, older floors with wide joints, sprung floors, or nailed/screwed . floors, as the dry filler may crack under these conditions.
- WB Filler can be used in combination with Junckers floor oils and lacquers.
- GEV-EMICODE: EC1^{Plus} Very low emission.

For professional use.

PRODUCT DESCRIPTION

Product: One-component acrylic dispersion.

Package sizes: 5 litres / 6 kg.

Appearance: Dries to the same colour as the added wood dust.

TECHNICAL DATA

Coverage: Approx. 20 m² per litre. Consumption will depend on the size of the joints and absorption capacity of the wood.

Before application: Shake well before use.

Mixing of sanding dust: 10 % by weight for smoothing and up to 20 % for gap filling.

Application tools: Broad full-edged spatula of stainless steel.

Substrate temperature: Minimum 15 °C.

Dilution: Not recommended.

Drying time at 20 °C and 50 % RH: Sanding: Approx. 60 minutes. Fully dried after 5-6 hours.

Cleaning of tools: Water immediately after use.

Storage: Lasts for 18 months if unopened and stored at 20 °C. Not to be exposed to temperatures below 5 °C. If the container has been opened, dry particles may form in the liquid. Use a sieve to filter these out before use.

Junckers Ltd. +44 1376 534700 / tech@junckers.co.uk Junckers Hardwood (USA) 202-334-8060 / sales@junckershardwood.com Junckers France S.A. +33 5 5944 8518 / commande@junckers.com Junckers Iberica S.A. +34 915 075 719 / orden@junckers.com Junckers S.r.I. +39 348 4405255 / gcsitaly@junckers.it Junckers Parkett GmbH. +49 0351-84387077 / info@junckers.de



DIRECTIONS FOR USE

Untreated/sanded floors:

- Ensure that the surface is clean, dry and free from dust, wax, oil, lacquer, grease, polish and soap residues.
- The final sanding before application should be carried out with 120-150 grit sandpaper.
- Mix sanding dust into the filler until a thick but spreadable paste is obtained.
- It is recommended to use sanding dust from a single or multi rotary-sanding machine. Dust from a belt sander is not suitable.
- Spread the paste using a stainless steel spatula.
- When dry, sand with 150-180 grit sandpaper.
- Note that low temperatures, high relative humidity and poor room ventilation can significantly increase drying time, as will gaps larger than 2 mm.
- Vacuum thoroughly and proceed with oil or lacquer application.

PRECAUTIONARY MEASURES

Before using the product, read the label on the container carefully and observe the recommended precautionary measures. See Safety Data Sheet for detailed information.